

Install Instructions for:

6ft (5ft & 1ft) panel kit with coping stone – In ground

Notes:

All Future Fencing panels & features are designed to accommodate a variety of lighting systems (supplied by others).

Due to the weight of the panels, we strongly advise the installation should be carried out by a minimum of two people.

There are three key elements to ensure the correct installation of the Waterfall feature:

- ❖ *Set your levels correctly by using string lines.*
- ❖ *Checking the levels after the installation of each post/panel*
- ❖ *It is important that the level of each post is checked regularly throughout the install, as this ensures the perfect stone wall look!*

1. Positioning the first Post:

- a. Dig a hole to the required depth – Approx. 2ft & position the post.
- b. Make sure the post is in line with the string-lines, use a spirit level on all four sides to ensure the post is level.
- c. Backfill the hole using a minimum of 2no. bags of post-mix & water. At this stage check again the first post is still lined up accurately before the post-mix sets.
- d. The other post holes are to be dug at approx. 1890mm apart, centre to centre.

2. Positioning the first Panel:

- a. Line up the 1ft & 5ft panels flat on the ground. The using the 2no. aluminium plates provided, screw the two panels together.
- b. Lift the panels up, insert the tongue into the groove of the first post and drop the hook into the slot on the top of the post.
- c. Insert the second post into the pre-dug hole. With the first panel raised, push the post up to the panel dropping the hook into the slot of the second post.
- d. BEFORE back-filling the second hole, check the direction against the string-line and all levels/height of the posts using a spirit level.

3. To install more panels please repeat no.2 & 3 instructions from above:

- a. Ensuring the direction, levels & height are checked as each post & panel is installed.

4. Installing the Coping Stones:

Nb. The coping stones are designed hollow.

- a. Place the first coping stone with an overhang of 2" over the end post.
- b. Take the second coping stone and cut the blank end off (*Note: if installing more panels, cut the blank end off*). Tap this end onto the tongue of the first coping stone. If a mortar line illusion is desired then leave a small gap.
- c. Screw the post & coping stone together using two small L shape brackets (*supplied with the kit*) offset on the underside.



Future Fencing Solutions Ltd - Head Office: Unit 4 Griffon Road, Quarry Hill Industrial Estate, Ilkeston, Derbyshire DE7 4RF
Tel 07842 368724 - Company No. 13302377 – VAT No. 385 3421 87

Please note: The 10-year product guarantee could be affected if the installation varies from the above instructions