

Install Instructions for:

Standalone Self-watering Planter – In ground

Notes:

All Future Fencing panels & features are designed to accommodate a variety of lighting systems (supplied by others).

Due to the weight of the panels, we strongly advise the installation should be carried out by a minimum of two people.

There are three key elements to ensure the correct installation of the Waterfall feature:

- ❖ Set your levels correctly by using string lines.
- ❖ Checking the levels after the installation of each post/panel
- ❖ Ensure the trough has a solid base to sit on.

1. Positioning the first Post:

- a. Dig a hole to the required depth – Approx. 2ft & position the post.
- b. Make sure the post is in line with the string-lines, use a spirit level on all four sides to ensure the post is level.
- c. Backfill the hole using a minimum of 2no. bags of post-mix & water. At this stage check again the first post is still lined up accurately before the post-mix sets.
- d. The other post holes are to be dug at approx. 1890mm apart, centre to centre.

2. Positioning the Planter trough & Panel:

- a. Lift the planter trough into position, inserting the tongue into the groove of the first post.
- b. Lifting the 5ft panel, drop the hook into the slot on the top of the post. The panel should sit snugly within the groove of the Planter trough.
- c. Insert the second post into the pre-dug hole, and lift the panel up so the hook drops into the top of the second post.
- d. BEFORE back-filling the second hole, check all levels.

3. Installing the Coping Stones:

Nb. The coping stones are designed hollow.

- a. Place the first coping stone with an overhang of 2" over the end post.
- b. Take the second coping stone and cut the tongue end off (*Note: if installing more panels, cut the blank end off.*) Tap both coping stones together. If a mortar line illusion is desired then leave a small gap.
- c. Screw the post & coping stone together using two small L shape brackets (*supplied with the kit*) offset on the underside.

4. Filling the Planter trough:

Nb. Please remember to check & top up the water level occasionally.

- a. Fill the planter with water up to the over-fill spout.
- b. Take the 4no. strips of hessian, (two per planter) and feed each end into the holes. (This should create a cross of hessian at the bottom.)
- c. Fill the troughs with soil ready for you to plant up!



FUTURE FENCING
SOLUTIONS

Future Fencing Solutions Ltd - Head Office: Unit 4 Griffon Road, Quarry Hill Industrial Estate, Ilkeston, Derbyshire DE7 4RF
Tel 07842 368724 - Company No. 13302377 – VAT No. 385 3421 87

Please note: The 10-year product guarantee could be affected if the installation varies from the above instructions